


# FITTING GUIDE BASE CABINET

## MILANO

HEIGHT: 29 15/16" - 34 1/2"  
WIDTH: 6" - 24"  
DEPTH: 25"


# FI.PK.FIT.013 - BASE1 MILANO



**(H)** x8 1 1/4"  
Screws



**(B)** x32 5/8"  
Screws



**(V)** x1 XL  
Space-Plug




**(K)** x2 L Bracket  
Large



Screws for attaching to walls and countertop are not provided as these vary depending on materials, thickness and construction. Ensure appropriate fixings for wall and countertop construction are used. Please refer to the specialist countertop supplier if these are required for solid surface countertops.



### Step 1.

Secure each leg into place with 2 x 5/8" screws **(B)**. Ensure legs are rotated as shown so that end panel is supported.




### Step 2.

Secure cabinet to the wall using XL Space-Plug **(V)**. Use a stud finder to locate the studs on the wall, drill pilot hole through the back brace of the cabinet into the wall at the stud location. Unwind the XL Space-Plug **(V)** until it contacts both surfaces, insert and tighten an appropriately sized screw through the back of the cabinet and the XL Space-Plug **(V)** into the wall. (Use appropriate fixing for wall construction where a stud is not available)



Sample Cabinet  
Shown





### Step 3.

Use 2 x 5/8" screws **(B)** to secure each of the L brackets **(K)** to the cabinet at either side. Then screw up and into the countertop.

### Step 4.

Screw up through the front rail into your countertop to secure it in place.



### Step 5.

Screw into any adjacent cabinets using 1 1/4" screws **(H)** provided to secure the cabinet. Screw just to the rear of the hinge plate and to the rear of the cabinet at the top and bottom. Place cover caps on the screw heads to conceal them.

Sample Hinge Shown

